



A103-160S/L Element Kit Instructions

MASTER PNEUMATIC - DETROIT, INC.

6701 -18 Mile Rd. | Sterling Heights, MI 48314 | Phone: (586) 254-1000 | Fax: (586) 254-6055 | Email: mp@masterpneumatic.com

JAA 08-10-06
Rev 10-01-08
(ECN 4451)

PRODUCT NUMBERS:

A103-160S
A103-160SE8
A103-160L
A103-160LE8


THANK YOU!

You have just purchased a quality Kit from Master Pneumatic.

With care in its installation and maintenance, you can expect it to have a long and economical service life. Before you go any further, please take a few minutes to look over this information, then save it for future reference and for the useful service information it contains.

Installation Procedures

NOTE: THE ADAPTOR MUST BE REMOVED.



Effective December 2008: A103-160S elements are replacing A103-160 Elements. Old A103-160 Elements can be used with manual drain Coalescent Filter models. Coalescent Filter models with auto drain or new float drain **MUST** use new A103-160S.

The A103-160S/L Element Kits replace the A103-133 Kits. Before installing the A103-160S/L Element Assembly for the **FIRST** time, the Adaptor must be removed. Coalescent Filters purchased **AFTER** October 2006 do **NOT** include the Adaptor, so Step 4 can be skipped.

INSTALLATION:

1. Depressurize and lockout air pressure.
2. Remove Bowl Ring and Bowl Assembly by turning counter-clockwise.
3. Remove OLD Coalescent Element Assembly by turning counter-clockwise.
4. Remove Adaptor by turning counter-clockwise using needle nose pliers. (See picture below.)
5. The NEW Coalescent Element Assembly can now be installed into Head by turning clockwise. (See picture below.)

STEP 4



STEP 5

