Master Pneumatic Detroit, Inc.

Micro-Lubrication Specialists



Precision Lubrication Systems for Air Tools, Hoists, and Air Motors







Master Pneumatic delivers ...

The critical nature of precision lubrication of pneumatic devices has existed for years. There are many ways to lubricate power tools, cylinders, motors, hoists and other types of actuation products....some more effective than others.

This booklet addresses primarily power tool lubrication. Additional information on lubrication of the other devices mentioned above is available. We have differing methods of providing positive lubrication for single and multiple spindle pneumatic power tools. Multiple spindle tools are usually lubricated by stacked injection lubricators which are activated either by a directional control valve or by a timing circuit. The oil lines are external and enter the air supply at the inlet to the air motor where the precise volume of oil specified is atomized.

These stacks are configured to deliver the specified amount of oil every 1, 5, or 10 cycles of the tool. The injectors are available with full stroke volume of ½, 1, or 2 drops per cycle. This volume is adjustable by way of a control knob in increments (46 clicks) but not to an off position. We can also include additional counter mechanisms which can take the lube event out to every 100 cycles of the tool. This is not common in multiple applications. For single tool lubrication systems, there are many variations. We could have stations which are: moving or stationary; single, double, or triple (or more); horizontal or vertical; centrally fed oil supply or individually filled reservoirs; and so on. The single most important point is to specify the correct lubricator. There are two basic types on the market, mist and single point.

Mist lubricators have a place in the lubrication market where the device to be lubricated is in very close proximity with a straight run to the tool, and no other devices in between. If this is not the case, the oil that is atomized exits the mist lubricator and "wets out": on the wall of the hose; at any bend in the circuit; and at any device between the mist lubricator and the power tool. Oil will find its way to the tool but it will be in slugs, intermittently.

Consistant, Reliable Lubrication

At this point the operator will usually turn down, or turn off the mist lubricator. Any tool manufacturer will tell you that their tool will operate best when it consistently receives the correct amount of oil. Too much or too little does not maximize tool performance and life.


Single Point Lubricators (SPL's) eliminate the over and under lubrication problems associated with power tools. SPL's deliver the correct amount of oil, at the tool, consistently. Every time the tool is cycled, oil is delivered via an internal oil capillary tube 6" before the tool in a fine, consistent state rather than in a slug periodically. The volume of oil can be as low as 1/20th of a drop up to ½ of a drop, and can be delivered every 1, 5, or 10 cycles of the tool. We use a variation of engineered coaxial fittings and disconnects to ensure the simultaneous delivery of air and oil from the SPL to the tool. This minimizes oil usage; reduces excess oil mist in the tool exhaust (which can end up on the employee or the product being manufactured); reduces power tool maintenance and downtime; increases tool performance and life.

Numerous articles have been written on the benefits of single point lubrication v. mist lubrication for power tools. They have been used in the Automotive Industry, as well as other industries, across the Western Hemisphere dating back to the very early 1970's. Further information can be supplied upon request.

Master Pneumatic can assist you in the design and build of the equipment needed upstream of the filter-regulator-lubricator combo. Our employees have been extensively involved in this arena for over 40 years. From the early stages of program design, through installation, and continuing on to the necessary training, M/P has the resources to see the program through.


PNEUMATIC TOOL LUBRICATION

CONVENTIONAL "MIST" METHOD



Oil pools in the low spots until air pushes it out in large slugs

MASTER PNEUMATIC'S "INJECTION" METHOD




Consistent lubrication results in consistent torque and tool

PNEUMATIC HOIST LUBRICATION


CONVENTIONAL "MIST" METHOD

Inconsistent oil delivery results in "Feast or Famine" lubrication



MASTER PNEUMATIC'S "INJECTION" METHOD


Precise oil delivery volumes, *delivered consistently*, results in improved hoist performance, longer hoist life, and lower repair costs.



No pooled or wasted oil

AUTOMATIC DRAIN FILTER






All pneumatic tools should receive clean, dry air.

Our Filters are standard with 5µ particulate elements. Our automatic drains remove water, as described above, when there is pressure differential in the sump and water is present.

Our double baffle system is superior to all other general line filters.

PRESSURE REGULATOR





The main valve closes and air pressure downstream (to the right) of the regulator is greater than 0 psi, the regulated pressure is proportional to the pressure applied by many clockwise turns have been applied to the adjusting knob (1).

the main valve (3) eventually equal and surpass the force of the adjusting spring (2).


When an air tool or valve is operated, air pressure on top of the diaphragm (5) decreases due to air being "drawn up" through the pitot port (6). The adjusting spring forces the main valve (3) open just enough for the air pressure on the diaphragm and main valve to balance the force of the adjusting spring (2) and maintain the set pressure. All standard M/P regulators are self-relieving. This means that if you turn the adjusting knob (1) counter-clockwise to reduce the air pressure, the reduced spring force on the diaphragm (5) allows the diaphragm to move downward, away from the relief valve (7). Air pressure downstream (to the right) of the regulator bleeds out through a small port in the Spring Cage (8) of the regulator.

Regulated pressure normally is read from an air gauge installed in the gauge port (9) of the regulator. Remove Key (10) to lock the regulator setting against unauthorized adjustments.

L28 SERIES LUBRICATOR

mp

With interchangeable replacement cartridges



SERV-OIL Single Point AIR TOOL INJECTION LUBRICATORS



WORKING MODE -INJECTING OIL FLOW VALVE Flow Sensing Disc-Open pressurizing Injector Air Exhausts when sensing Disc is 1/8" Oil Delivery Line closed **ADJUSTABLE COUNTER** Operates on 1, 5, or 10 actuations **Counter Indicator Button** Nylon Bowl Counter Adjusting Switch **SERVO-METER INJECTOR** Manual Override Transparent Oil Volume Sight Glass Control Oil dispensing Oil Metering Metering Pin Indicator Ball Chamber Check Valve

Adjustable Fluid Output


	½ Drop		
Clicks	ml	Clicks	ml
Full			
Volume 46	0.0150	23	0.0083
45	0.0147	22	0.0080
44	0.0144	21	0.0077
43	0.0141	20	0.0074
42	0.0138	19	0.0071
41	0.0135	18	0.0068
40	0.0132	17	0.0065
39	0.0129	16	0.0062
38	0.0127	15	0.0059
37	0.0124	14	0.0056
36	0.0121	13	0.0053
35	0.0118	12	0.0050
34	0.0115	11	0.0047
33	0.0112	10	0.0045
32	0.0109	9	0.0042
31	0.0106	8	0.0039
30	0.0103	7	0.0036
29	0.0100	6	0.0033
28	0.0097	5	0.0030
27	0.0094	4	0.0027
26	0.0091	3	0.0024
25	0.0088	2	0.0021
24	0.0086	1	0.0018

	1 Drop		
Clicks	ml	Clicks	ml
Full			
Volume 46	0.0300	23	0.0165
45	0.0294	22	0.0159
44	0.0288	21	0.0154
43	0.0282	20	0.0148
42	0.0277	19	0.0142
41	0.0271	18	0.0136
40	0.0265	17	0.0130
39	0.0259	16	0.0124
38	0.0253	15	0.0118
37	0.0247	14	0.0112
36	0.0241	13	0.0107
35	0.0236	12	0.0101
34	0.0230	11	0.0095
33	0.0224	10	0.0089
32	0.0218	9	0.0083
31	0.0212	8	0.0077
30	0.0206	7	0.0071
29	0.0200	6	0.0066
28	0.0195	5	0.0060
27	0.0189	4	0.0054
26	0.0183	3	0.0048
25	0.0177	2	0.0042
24	0.0171	1	0.0036

Adjustable Fluid Output cont.

	2 Drop		
Clicks	ml	Clicks	ml
Full			
Volume 46	0.0600	23	0.0360
45	0.0590	22	0.0350
44	0.0579	21	0.0339
43	0.0569	20	0.0329
42	0.0558	19	0.0318
41	0.0548	18	0.0308
40	0.0537	17	0.0298
39	0.0527	16	0.0287
38	0.0517	15	0.0277
37	0.0506	14	0.0266
36	0.0496	13	0.0256
35	0.0485	12	0.0245
34	0.0475	11	0.0235
33	0.0464	10	0.0225
32	0.0454	9	0.0214
31	0.0444	8	0.0204
30	0.0433	7	0.0193
29	0.0423	6	0.0183
28	0.0412	5	0.0172
27	0.0402	4	0.0162
26	0.0391	3	0.0152
25	0.0381	2	0.0141
24	0.0371	1	0.0131


Coaxial Fittings



The o-ring probe makes an ID/OD seal that prevents leakage of the internal oil capillary tube. Installing and removing these direct connect Coaxial Fittings does not adversely affect the function of the capillary tube.

Coaxial Fittings

Single Point Lubricators (SPL's) can be installed vertically as well as horizontally. In these applications, an external oil supply is required. The supply can be a dedicated reservoir or a Central Oil Delivery System.



Single Point Lubricators

Examples of available SPL's

SPL with integral 10 ounce Reservoir and pulse counter. 1/2" or 3/4" NPTF Female ports (BSPP optional)

SPL with external 10 ounce reservoir and pulse counter. 1/2" or 3/4" NPTF Female ports (BSPP optional) Shown with Coaxial Socket





SPL without reservoir, with a frequency generator. 1/2" or 3/4" NPTF Female ports (BSPP optional)

SPL without reservoir, with double pulse counter. 1/2" or 3/4" NPTF Female ports (BSPP optional)





FRL Combinations

Filter-Regulator-Lubricator (FRL) Combinations are virtually endless. Below are examples with an integral reservoir.




Lockout valve, Filter, Regulator, SPL with Integral Reservoir, Coaxial Elbow, Quick disconnect socket and Coiled urethane hose assembly



Lockout valve, Filter, Regulator, SPL with Integral Reservoir, Coaxial Elbow, manual Coaxial male fitting and straight urethane hose assembly

FRL Combinations

Filter-Regulator-Lubricator (FRL) Combinations are virtually endless. Below are examples with an external reservoir.



Lockout valve, Filter, Regulator, SPL with External Coaxial Elbow. Quick disconnect socket and Coiled urethane hose assembly

Lockout valve,

Coaxial Connections

Various Coaxial Connectors are made for the numerous FRL Combinations. Below are a few examples.



Coaxial 90° Elbows are available in 1/2" & 3/4" NPTF. They are used to position the Coaxial Whip Hose and/or Tool Hose Assemblies perpendicular to the SPL. (shown left)



Direct Zero Pressure Quick Connect Coaxial Sockets are available in 3 configurations (shown left):


- * 3/4 Series x 3/4" Male NPT
- * 1/2 Series x 3/4" Male NPT
- 1/2 Series x 1/2 " Male NPT


Coaxial Quick Connect Plugs (shown right) are made to connect to the Coaxial Sockets which are installed in the SPL, Coaxial Elbow or on the end of the Coaxial Whip Hose Assembly



Male Coaxial Connectors (shown right) are made to thread into the SPL or Coaxial Elbow. These are NOT quick connects and the air supply must be off to install or remove.








Assembly processes determine how air preparation products (FRL's) are installed. Some applications require the employee to be able to move around the product to be assembled. In these applications, the FRL Combo may be stationary and the Coaxial Tool Hose may be mounted on a balancer, or coiled to allow the employee to be mobile BUT minimize hose on the floor.


Single FRL Traveling



Many vehicular assembly processes require air preparation products (FRL's) to move on tool rail. The employee is able to move with the product to be assembled on the conveyor. Factors that need to be considered are too numerous for this publication but a partial list would include:

- Tool rail type and height
- Process time allowed in station.
- * Number of jobs to be performed and by how many employees
- Type of tools being used
- * Oil supply method


Single FRL Traveling



In the illustration above, a Single Traveling FRL Combo was used. The SPL does not include the integral reservoir. Instead, a Central Oil Delivery System was installed to keep oil supplied to over 1000 SPL's. This design is compact, lower cost, and requires less maintenance.

The site dome is used during start-up of the system and then functions as visual indication of oil delivery. The short length of tubing installed at the inlet to the site dome includes a fluid filter and quick connects to attach to the festoon hose assembly. The Balancer Bar is used to suspend a tool balancer. The Coaxial Whip Hose Assembly was designed to extend to 2 meters off the floor.

Triple FRL Traveling




Above, a Triple Traveling FRL Combo is illustrated. These SPL's include the integral reservoirs. All three SPL's are connected with 3/8"OD tubing to allow maintenance to fill only one SPL to keep all three full. This design was built for an assembly process where three separate tools, each having different pressure requirements, were used in the same workstation.

Other options that could have been included are:

- * Remote or Central Fill
- * Balancer Bars
- * Lower profile

The Coaxial Whip Hose Assemblies were designed to extend to 2 meters off the floor.

Multiple FRL Traveling




Above, a Quad Traveling FRL Combo is shown. These SPL's do not include the integral reservoirs. All four SPL's are connected with 3/8" OD tubing connected to a 1 liter reservoir mounted on the Load Bar. This allows maintenance to fill only one reservoir, from the floor, to keep all four SPL's with supply oil. This design was built for an assembly process where two employees were operating four separate tools, each having different pressure requirements, in the same workstation.

A very compact design for the application.

Bridges

Bridges are often used to give employees mobility in one or more locations. Multiple tools and fixtures can be suspended from the bridge and the bridge can move on tool rail runways within a work station. Depending on space and conveyor line speed, numerous employees can perform multiple tasks in close proximity to each other.




In the drawing above, up to four employees are performing assembly operations in a single station. The can move back and forth with their tools on the bridge and the bridge can be moved with the assembly line.

One common reservoir is installed in the middle of the bridge at the point compressed air is brought to the bridge. Air and oil are delivered by twinline hose to the outside of the bridge and then delivered to coiled dual bond hose assemblies to the traveling FRL

Coaxial Whip Hose Assemblies

The Coaxial Whip Hose Assembly is used to allow employees to disconnect the Coaxial Tool Hose Assembly from the SPL without the use of a ladder. They are to extend from the SPL to approximately 2 meters from the floor in most plants, this is enough height to prevent an employee from a head injury and yet low enough to disconnect the Coaxial Tool Hose Assembly.



6'8" from floor


Unlike the Coaxial Tool Hose Assembly, the Whip Assembly has the internal oil capillary tube connected at both ends of the assembly. The hose has an inner non-stretch tube.

The upstream end has a Direct Connect Coaxial Male nipple to connect to either a Coaxial 90° Elbow or directly to the SPL. The downstream connector is a Coaxial Quick Disconnect Socket.

The assemblies can be made in any length, and made in either 1/2" or 3/4" ID hose.

Coaxial Hose Assemblies Selection Criteria

The Coaxial Tool Hose Assembly is a hose assembly with an internal oil line. The oil line is connected to a Coaxial Plug for quick connecting to the FRL Combo and ends within the last foot of hose before the tool with an oil check valve. It is at this point where in rushing air shears the oil and dispenses a small amount of oil, consistently, to the tool.



There a many factors to consider when choosing the correct Coaxial Tool Hose Assembly. Some of the factors to consider are:

- * Tool rail height
- * Ergonomics
- * Safety
- * The job to be performed
- * Commonality
- * Air tool SCFM requirements
- * Cost


These are only a few and are not necessarily listed by importance.

Coaxial Tool Hose Assemblies

These Assemblies are made in multiple configurations.

The hose can be:

- Rubber
- Urethane (reinforced w/ inner braid or non reinforced)
- Different colors
- Straight or Coiled
- If coiled, straight tails on either side of the coil in various lengths
- Coaxial Plug on upstream end either 1/2" or 3/4" series
- Quick disconnect on the tool end
 - 1. Zero pressure connect / disconnect
 - 2. Industrial interchange or hybrid
 - 3. Non mar for product protection (bump & scratch)
 - 4. High flow
- Manufactured by M/P or by the user with the proper training by M/P



Central Oil Delivery System

The installation of a Central Oil Delivery System provides a number of benefits to the end user. The system consists of a ¾" black pipe header installed as a closed loop.

We can design the system with isolation valves at appropriate intervals, vents with shut off valves (see drawing on next page), and takeoffs at 5' (typ.) or 10' centers to feed the Single Point Lubricators (SPL's). Once the system is purged and filled,maintenance employees no longer need to service hard to reach, or hard to find, reservoirs on a regular basis. There is one point per loop that needs to be serviced, from floor level, in much less frequency.


Each header loop is serviced by a gravity feed reservoir mounted above the loop (see drawing on next page). We can supply a 30 gallon translucent tank which includes the following:

- * HI-LO level switch
- * Visual level indicator lamps
- * Full useable 25 gallon range
- * Air shut off valve
- * Inlet filter necessary quick disconnects for air and oil supply Vibration isolation

hoses


 * Electrical junction – control box we design for each system to address individual plant requirements.

A typical system layout is shown below.



Central Oil Delivery System

Gravity Feed Oil Delivery



Oil header loops can be up to 1000' in total length. Hundreds of reservoirs can be kept full with only one tank to periodically fill from the floor level.



For more information on Serv-Oil precision lubrication and your Authorized Distributor contact Master Pneumatic or visit our website.

www.masterpneumatic.com

Phone: (586) 254-1000

Fax: (586)-254-6055

Master Pneumatic Detroit, Inc. 6701 Eighteen Mile Road Sterling Heights, MI 48314

Our customers have found pneumatic tools using Master Pneumtic's Serv-Oil Precision lubricators, which receive a small amount of oil consistently, will:

- Increase tool life 2.5 3 times
- Reduce repair costs by 50-90%
- Reduce oil in environment there by improving health & safety conditions
- Improve productivity
- Improve tool performance
 - Torque consistency
 - power
 - heat
 - etc.





www.masterpneumatic.com



Publication T2004-cam Rev. 10-03-15